

Document Title: ZL6 Cellular Board Replacement Instruction Sheet		Part # 18318	
		Release Date: 5.31.2019	
Rev	Description	Revision By	Date
00	Initial Release per DCO 04370 tied to PCR 03661	LAJ	5.31.2019

Production Filename: http://publications.metergroup.com/Instruction%20Sheets/18318_ZL6-IS_CellularBoardReplacement_PRINT.pdf

Working File Path:

/Volumes/GoogleDrive/Team Drives/Product Number Library/18300-18399/18318/


Dimensions: 5.375" wide x 10" tall, folded in half (finished folded size is 5.375" wide x 5" tall)

Colors: CMYK/Full color 4/4

Printer: In-house printing

Material: 11x17 Card stock (landscape), Bright White, 216 g/m² (folding cardstock)

Image below is for reference only. Not to scale.



ZL6 Cellular Board Replacement

18318-00
5.31.2019

The cellular board in the ZL6 data logger should be replaced if it malfunctions or if performing an upgrade. These step-by-step instructions will explain the replacement process. A #1 Phillips screwdriver and a wooden stick (included) is required for installation.

ACCESS CELLULAR BOARD

CAUTION: Do not disconnect the solar panel wiring.

NOTE: Update the logger firmware to the latest version using the **Check for Logger Firmware Updates** option in the ZENTRA Utility Help menu.

1. Remove a battery to turn off the ZL6.
2. Press the TEST button to clear power in the logger.
3. Remove the four screws from the main board using a Phillips screwdriver.

