

Decagon Devices, Inc. Product Market Information Sheet

Product: Decagon DataStation

Description: Base Station which receives data from up to 80 Em50R data loggers using a 900 MHz radio frequency. The DataStation is designed to be plugged in to direct power and continuously “listens” for data packages from Em50R data loggers. A “Confirm Delivery” mode in the DataStation and Em50R data loggers ensures that all data received by the DataStation is complete (no partial transmissions). Currently, the only other device that can receive data from the Em50R data loggers is Decagon’s RM-1, which can only receive data from one data logger at a time.

Distributors of Product: Decagon Devices, Inc. is the sole distributor of the DataStation in the USA to universities and other research institutions.

Competitors with similar products: None known with the capabilities of the DataStation.