

# Decagon Devices, Inc. Product Market Information Sheet

---

**Product:** Decagon Em50G

**Description:** Data logger containing 5 ports to monitor and record data from Decagon sensors. Data logger is powered by 5 AA batteries and utilizes the Decagon Data Services, which includes an on-board GPRS SIM card, cellular service, and a server located at Decagon Devices in Pullman, WA. Data are accessed using Datatrak 3 software, and are password protected. The data logger can monitor both digital and analog sensors from Decagon's sensor line including, but not limited to, the 5TE, 5TM, EC-5, and 10HS.

Data from the Em50G can be uploaded to the server up to 6 (six) times per day. Therefore, data can be logged for an extended amount of time (6+ months) using the included AA batteries. In the event of a communication failure, data will still be recorded and stored on the storage device within the logger.

**Distributors of Product:** Decagon Devices, Inc. is the sole distributor of the Em50G in the USA to universities and other research institutions.

**Competitors with similar products:** None known with the capabilities of the Em50G logger.