

Document Title: USGA Moisture Meter INSERT		Part # 18061	
		Release Date: 7.2026	
Rev.	Description	Revision By	Date
00	Permissions for METER local printing from USGA, release of file per Netsuite Record Requests 28130	EMR	7.2026

Production File Path:

http://publications.metergroup.com/Quick%20Start%20Guides/18061_MoistureMeter_Print.pdf

Working File Path:

[SharePoint/Sites/Product Number Library/18000-18099/18061/](#)

Material:

100# silk cover

Dimensions:

5.5 x 8.5 inches

Colors: CMYK, 4/4

IMAGE (note this image is not to size and is just for identification):



INSTRUCTIONS TO PERFORM A SOIL TEST:

1. Ensure the USGA Moisture Meter is turned on by pressing the power button. You should see the battery LEDs illuminated and the Bluetooth LED blinking
2. Open the DEACON app and select "Add New" from the bottom navigation bar
3. Select "Soil Test"
4. Connect to your USGA Moisture Meter in the connection screen
5. Your phone will track you as you move through the golf course, but if the position is not accurate, you may press the blue button in the bottom right of the map to turn GPS tracking off
6. Once at the desired location, insert the moisture meter fully into the ground and press one of the two measure buttons on the left or right of the control panel
7. Repeat step 6 until you have measured all of the desired locations on that surface
8. Press "Complete Test" to complete the test and save the results to the Calendar

